

Table of Contents

Chapter 1 Installation Procedures

Jumpers	1
Clear Password: CPW	2
Flash ROM Type Selection: EP1, EP2	2
Power Supply Type Selection: PWR.....	3
CPU to SRAM Data Transacting Mode Selection: SRAM	3
DIMM Frequency: CLK4 , SDRAM1 & System Frequency: SDRAM2, SDRAM3.....	4
CPU External (BUS) Frequency: CLK1, CLK2, CLK3.....	6
CPU to Bus Frequency Ratio: FREQ1, FREQ2, FREQ3	6
Set CPU Voltage	7

Chapter 2 BIOS Setup

CMOS Setup Utility.....	9
Standard CMOS Setup	10
Hard Disk Configurations.....	10
Software Turbo Speed	11
BIOS Features Setup.....	12
Chipset Features Setup.....	15
Power Management Setup.....	18
PNP/PCI Configuration	22
Load BIOS Defaults	24
Load Setup Defaults.....	24
Integrated Peripherals	24
Supervisor/User Password.....	28
IDE HDD Auto Detection	29
Save and Exit Setup	30
Exit without Saving.....	30
